

LYNK Connections Diagrams

LYNK Overlay Model Connections:

- MDB Port
- DEX Port
- Antenna Port

The upper-left port is only used when reflashing the telemeter. For more information on the reflashing process, visit the [GlobalConnect Technical Support site](#).



LYNK Full Size Model Connections:

- MDB Port
- DEX Port
- Antenna Port

The top-row ports are used only when reflashing the telemeter. The optional Ethernet port should **not** be used to plug in the DEX cable.

