



Price Check, Service Menu, and Quick DEX

User Guide



Contents

Price Check Feature on LYNK Telemeters	2
LYNK Telemeter Service Menu.....	3
Quick DEX on LYNK Telemeter.....	4

Price Check Feature on LYNK Telemeters

Use the LYNK Telemeter's **Price Check** feature to view product prices before a purchase.

! To Perform a Price Check:

1. **Press** your fingertip to bottom of the screen to access the price check feature.
2. **Select a product** on the machine to view the item's price.
3. **Review** the product price displayed on the screen.

Press the bottom of the screen to return to the main page after checking a price.

LYNK Telemeter Price Check Steps



Note: Images reflect Full Size LYNK model.

LYNK Telemeter Service Menu

View important device information and run self-checks in the **LYNK Service Menu**:

! To Access the LYNK Service Menu:

1. **Press** the main language (e.g. English) button **5** times. (Full Size: Top, Overlay: Bottom)
2. Enter your **Operator PIN** to access the Service Menu commands.
3. **Select** a command: *Reboot*, *Service DEX*, or view *All Options*.

The **All Options** command allows you to perform the following **service checks**:


- Communication Check
- Network Check
- DEX Check
- Credit Card Transaction Check
- GC Loyalty Transaction Check
- Move Telemeter

LYNK Telemeter Service Menu Steps

1. Press Language Button 5x

2. Enter Operator PIN

3. Choose Check Type



Quick DEX on LYNK Telemeter


The LYNK Telemeter supports **Quick DEX** to easily get DEX information on a device.

! To Perform a Quick DEX

1. Make sure the LYNK Telemeter is on the main screen.
2. **Press** 5 times on the **middle-right** area of the screen.
3. Perform the Quick DEX.

LYNK Telemeter Quick DEX Steps

Full Size Model Press Area



Overlay Model Press Area



Press the highlighted area **5 times** to perform a **Quick DEX**