

LYNK Telemeter Quick Reference Guide

What do I need to start the installation?

1. **Info:** You need the Operator ID, Operator PIN, and Machine Asset ID to start the installation. Contact LYNKSupport@globalconnect.biz for Operator ID and PIN.
2. **Equipment:** Telemeter, Payment Options sticker, and cables in the box. Some machines require additional cables - order from the [GlobalConnect Marketplace](#).
 - a. For Streamware/Vendmax operators: Order DEX Y Cable
 - b. Vendo HVV 72x: Order DEX Adapter Kit/Cable
 - c. AP machines with SL & ST boards: Order DEX Adapter Kit/Cable
 - d. AMS SENSIT I, II, and some III: Order DEX Adapter Kit/Cable
3. **Tools:** Wrench for antenna, cable ties

LYNK Ports & Connections



LYNK Support Documentation



LYNK Support Videos



For additional help, contact LYNK Customer Service

LYNKSupport@globalconnect.biz

336-546- – ask for LYNK Support



Useful Resources

- Known Issues List of Machines
<https://docs.google.com/spreadsheets/d/1kAGqYCdGmI7IQtkP1Dt3AtkzfUtWPqBQhgWOJnoFnDU/edit?usp=sharing>
- How-to articles <https://lynkgc.atlassian.net/wiki/spaces/LS/pages/262179/How-to+articles>
https://drive.google.com/drive/folders/1Nid2KFZok_F-wRKMA9Vk9flu-AJPcuZJ?usp=sharing
- YouTube Channel of all LYNK Support Videos
<https://www.youtube.com/channel/UC64tVRk08Gt38kxmM16UiLw>
- Resources list <https://www.globalconnectservices.com/technical-support>
- Ports & Connections Diagram
(<https://www.globalconnectservices.com/uploads/lynkportsandconnectionsguide.pdf>)